MLBX
WIRELESS LASER MOBILE MINI MOUSE
USER MANUAL
MODEL 177078

MANHATTAN™

MAN-177078-UM-1208-04

INTRODUCTION

Thank you for purchasing the MANHATTAN® MLBX Wireless Laser Mobile Mini Mouse, Model 177078.

Its compact-sized, ambidextrous shape and three-button configuration provide direct access to essential commands with minimal wrist movement. A non-slip texture applied to critical surfaces helps provide a secure, comfortable grip. Powerful 2.4 – 2.48 GHz Bluetooth Class II technology provides an effective range of up to 10 m (33 ft.) that easily pairs with Bluetooth-enabled notebook computers for consistent performance in the office, at home or from a mobile workspace without tangled cables or undependable receivers.

The top-mount push-button instantly shifts resolution among from 500 to 3000 dpi to suit a wide range of applications, including routine computing tasks and computer games requiring a fine touch. Auto power management and on/off switch help maintain proper battery levels with a handy retractable cable that recharges while in use for uninterrupted operation.

Plug and Play installation and compatibility with Windows 2000/XP/Vista offer quick and easy installation. With no mechanical or rolling parts to wear or fail, the MANHATTAN MLB Wireless Laser Mobile Mini Mouse requires little maintenance for reliable service.

By following the instructions in this user manual — or the simpler setup procedure in the printed quick install guide included with the product — you can soon be appreciating these features mentioned above, plus a Lifetime Warranty. (For a complete list of country-specific warranties, go to www.manhattan-products.com/warranty.)

Package Contents

- MLBX Wireless Laser Mobile Mini Mouse
- Retractable cable reel
- (2) AAA batteries
- Carrying bag
- Quick install guide

INSTALLATION

Before installing the MLBX Wireless Laser Mobile Mini Mouse, make sure that the Bluetooth protocol is available on your computer — either on the hard drive or through a Bluetooth dongle inserted in a USB port — as indicated by the Bluetooth icon (right), which typically appears in the desktop system tray.

Different software is available to enable installation. (Widcomm and IVT screen images are presented in the procedures below as examples.) Otherwise, the built-in Microsoft software can be used (the second connection procedure of the three listed below in Bluetooth Connection).

1. Press the cover release and remove the battery compartment cover.
2. Insert the two included AAA rechargeable batteries, matching the +/– polarity as marked inside the battery compartment.
3. Replace the cover so it snaps securely back in place.
4. If the Low Power LED flashes, charge the mouse by connecting it to the computer with the included retractable USB cable. ***NOTE:*** The mouse can be used while charging.
5. Set the Power switch on the underside to the On position to place the mouse in Discovery mode.
6. Press the Connect button until the Low Power LED blinks slowly.
7. Open your computer's Bluetooth utility (built into the operating system or installed as a third-party utility) and scan for available Bluetooth devices.
8. When "Bluetooth Wireless Laser Mouse" displays, select it.
9. When prompted for a passkey, enter 0000. The operating system will detect the new device and automatically install the driver(s), making the mouse ready for use.





BLUETOOTH CONNECTION

Connecting with Widcomm (Recommended)

1. Double-click the Bluetooth icon and click “Next” on the Setup screens until the system finds the mouse and the Bluetooth Device Selection screen displays (below).


Bluetooth Device Selection
Select a device
Remote devices must be in Discoverable mode for this computer to find them. For assistance in making a remote device discoverable, refer to the remote device's documentation.
Bluetooth Wireless Mouse
SHIMY
Search Again
Show all devices
If the device you are looking for is not in the list, verify that the device has power and is operational. On some devices, you must press the Connect button to make the device discoverable.
< Back
Next >
Cancel

2. Select “Bluetooth Wireless Mouse” and click “Next.”

3. When the Confirmation Required prompt displays, click “Click here.” The mouse is now operational and ready for use.

Confirmation Required
Connection with Bluetooth Wireless Mouse has been established successfully.
To confirm that the correct mouse is being connected, please use it to click the button below.
Click here: 57

If unused for 10 minutes, the mouse transfers to the Power Save mode. Double-click the left button to reactivate the mouse. Once connected, double-clicking the left button will reactivate the mouse on subsequent power-ups without the need to reconnect.

If a disconnection occurs during the procedure, just reconnect the mouse. It may be necessary to open the Bluetooth Dongle Software window, disable the mouse, then reconnect.

If you're using the Widcomm Bluetooth software, right-click on the mouse and select "Status" (below) to check the battery power and set up the low battery alarm.





Connecting with Built-in Microsoft Software)

1. Double-click the Bluetooth icon to display the Bluetooth Devices screen; then click “Add” to display the Add Bluetooth Device Wizard welcome screen.



2. Select “My device is set up and ready to be found” (or “facility is ready for searching,” depending on the OS).

Add Bluetooth Device Wizard
Welcome to the Add Bluetooth Device Wizard
Before proceeding, refer to the "Bluetooth" section of the device documentation. Then set up your device so that your computer can find it:
- Turn it on
- Make it discoverable (visible)
- Give it a name (optional)
- Press the button on the bottom of the device (keyboards and mice only)
My device is set up and ready to be found.
Add only Bluetooth devices that you trust.
< Back
Next >
Cancel

3. Select “Bluetooth Wireless Mouse” and click “Next.”


Add Bluetooth Device Wizard
Select the Bluetooth device that you want to add.
SHIMY
New device
Bluetooth Wireless Mouse
New Device
If you don't see the device that you want to add, make sure that it is turned on. Follow the setup instructions that came with the device, and then click Search Again.
Search Again
< Back
Next >
Cancel

4. Select “Don’t use a passkey” (or “No Password”) and click “Next,” then “Finish” to complete the procedure.


Add Bluetooth Device Wizard
Do you need a passkey to add your device?
To answer this question, refer to the "Bluetooth" section of the documentation that came with your device. If the documentation specifies a passkey, use that one.
Choose a passkey for me
Use the passkey found in the documentation:
Let me choose my own passkey:
Don't use a passkey
You should always use a passkey, unless your device does not support one. We recommend using a passkey that is 8 to 16 digits long. The longer the passkey, the more secure it will be.
< Back
Next >
Cancel

Connecting with IVT

1. Double-click the Bluetooth icon to open the management window; from the My Bluetooth menu, select “Bluetooth Device Discover” (or “Search for Bluetooth facilities”), or click the orange ball on the screen.



2. When the mouse icon appears on the screen, highlight it and right-click, then select “Refresh Services.”
3. Highlight the mouse icon again, right-click and select “Connect” then “Bluetooth Input Service” (or “Bluetooth Human Interface Device Service”) to complete the installation.

OPERATING TIPS

- To save battery power, operate the mouse on a bright surface with a fine texture. A very dark surface will result in higher power consumption.
- Avoid using the mouse on glass, mirrored or glossy surfaces, as it may work improperly or not at all.
- To ensure optimal transmission distance, don't use the mouse on a metal surfaces (as elements such as iron and aluminum can interfere with its performance).
- If you're unable to connect the MLBX Wireless Laser Mobile Mini Mouse to the computer, or if the mouse works erratically, check these possible corrective measures:
  - Before installing the mouse, make sure the Bluetooth dongle has been installed and activated.
  - Press and release the Connect button on the underside of the mouse and confirm that the red LED lights.
  - Make sure the mouse is within the effective operating range of 10 m (approx. 33 feet).
  - Make sure no change has been made to the Bluetooth installation since the mouse installation. If so, re-install the mouse.
  - If your Bluetooth is connected to other Bluetooth devices, confirm that the Bluetooth speed is adequate.
  - Check the batteries.

SPECIFICATIONS

Standards and Certifications
- USB 1.1 (recharge only)
- CE
- FCC
- R&TTE
- RoHS
- WEEE

General
- 2.4 – 2.48 GHz Bluetooth Class II; effective range up to 10 m (33 ft.)
- Mouse: laser, 500/1000/1500/2000/2500/3000 dpi resolution
- Controls: right, left and center mouse buttons with scroll wheel; power switch (on/off); top-mount resolution adjustment button
- Automatic power save/power off mode
- Material: ABS plastic
- Compatible with Bluetooth-enabled Windows and Mac systems

Dimensions
- Mouse: 9.8 x 5.6 x 3.5 cm (3.9 x 2.2 x 1.4 in.); 73.3g (2.6 oz.)
- USB retractable cable: A-type male to mini-B-type male, 76 cm (30 in.)

Environmental
- Operational temperature: 0 – 45°C
- Storage temperature: -10 – 85°C
- Working humidity: <85%

Package Contents
- MLBX Wireless Laser Mobile Mini Mouse
- Retractable cable reel
- (2) AAA batteries
- Carrying bag
- Quick install guide

WASTE ELECTRICAL & ELECTRONIC EQUIPMENT

Disposal of Electric and Electronic Equipment

(applicable in the European Union and other European countries with separate collection systems)

ENGLISH

This symbol on the product or its packaging indicates that this product shall not be treated as household waste. Instead, it should be taken to an applicable collection

point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences to the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. If your equipment contains easily removable batteries or accumulators, dispose of these separately according to your local requirements. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, contact your local city office, your household waste disposal service or the shop where you purchased this product. *In countries outside of the EU:* If you wish to discard this product, contact your local authorities and ask for the correct manner of disposal.

DEUTSCH

Dieses auf dem Produkt oder der Verpackung angebrachte Symbol zeigt an, dass dieses Produkt nicht mit dem Hausmüll entsorgt werden darf. In Übereinstimmung mit der Richtlinie 2002/96/EG des Europäischen Parlaments und des Rates über Elektro- und Elektronik-Altgeräte (WEEE) darf dieses Elektrogerät nicht im normalen Hausmüll oder dem Gelben Sack entsorgt werden. Wenn Sie dieses Produkt entsorgen möchten, bringen Sie es bitte zur Verkaufsstelle zurück oder zum Recycling-Sammelpunkt Ihrer Gemeinde.

ESPAÑOL

Este símbolo en el producto o su embalaje indica que el producto no debe tratarse como residuo doméstico. De conformidad con la Directiva 2002/96/CE de la UE sobre residuos de aparatos eléctricos y electrónicos (RAEE), este producto eléctrico no puede desecha se con el resto de residuos no clasificados. Deshágase de este producto devolviéndolo a su punto de venta o a un punto de recolección municipal para su reciclaje.

FRANÇAIS

Ce symbole sur le produit ou son emballage signifie que ce produit ne doitpas être traité comme un déchet ménager. Conformément à la Directive 2002/96/EC sur les déchets d'équipements électriques et électroniques (DEEE), ce produit électrique ne doit en aucun cas être mis au rebut sous forme de déchet municipal non trié. Veuillez vous débarrasser de ce produit en le renvoyant à son point de vente ou au point de ramassage local dans votre municipalité, à des fins de recyclage.

ITALIANO

Questo simbolo sui prodotto o sulla relativa confezione indica che il prodotto non va trattato come un rifiuto domestico. In ottemperanza alla Direttiva UE 2002/96/EC sui rifiuti di apparecchiature elettriche ed elettroniche (RAEE), questa prodotto elettrico non deve essere smaltito come rifiuto municipale misto. Si prega di smaltire il prodotto riportandolo al punto vendita o al punto di raccolta municipale locale per un opportuno riciclaggio.

POLSKI

Jeśli na produkcie lub jego opakowaniu umieszczono ten symbol, wówczas w czasie utylizacji nie wolno wyrzucać tego produktu wraz z odpadami komunalnymi. Zgodnie z Dyrektywą Nr 2002/96/WE w sprawie zużytego sprzętu elektrycznego i elektronicznego (WEEE), niniejszego produktu elektrycznego nie wolno usuwać jako nie posortowanego odpadu komunalnego. Prosimy o usuniecie niniejszego produktu poprzez jego zwrot do punktu zakupu lub oddanie do miejscowego komunalnego punktu zbiórki odpadów przeznaczonych do recyklingu.

WARRANTY INFORMATION

ENGLISH: For warranty information, go to www.manhattan-products.com/warranty.
DEUTSCH: Garantieinformationen finden Sie unter www.manhattan-products.com/warranty.
ESPAÑOL: Si desea obtener información sobre la garantía, visite www.manhattan-products.com/warranty.
FRANÇAIS: Pour consulter les informations sur la garantie, visitez www.manhattan-products.com/warranty.
POLSKI: Informacje dotyczące gwarancji znajdują się na stronie www.manhattan-products.com/warranty.
ITALIANO: Per informazioni sulla garanzia, accedere a www.manhattan-products.com/warranty.

EN MÉXICO: Póliza de Garantía MANHATTAN — Datos del importador y responsable ante el consumidor IC Intracom México, S.A. de C.V. • Av. Interceptor Poniente # 73, Col. Parque Industrial La Joya, Cuautitlan Izcalli, Estado de México, C.P. 54730, México. • Tel. (55)1500-4500

La presente garantía cubre los siguientes productos contra cualquier defecto de fabricación en sus materiales y mano de obra.

A. Garantizamos los productos de limpieza, aire comprimido y consumibles, por 60 dias a partir de la fecha de entrega, o por el tiempo en que se agote totalmente su contenido por su propia función de uso, lo que suceda primero.
B. Garantizamos los productos con partes móviles por 3 años.
C. Garantizamos los demás productos por 5 años (productos sin partes móviles), bajo las siguientes condiciones:
    1. Todos los productos a que se refiere esta garantía, ampara su cambio físico, sin ningún cargo para el consumidor.
    2. El comercializador no tiene talleres de servicio, debido a que los productos que se garantizan no cuentan con reparaciones, ni refacciones, ya que su garantía es de cambio físico.
    3. La garantía cubre exclusivamente aquellas partes, equipos o sub-ensambles que hayan sido instaladas de fábrica y no incluye en ningún caso el equipo adicional o cualesquiera que hayan sido adicionados al mismo por el usuario o distribuidor.

Para hacer efectiva esta garantía bastara con presentar el producto al distribuidor en el domicilio donde fue adquirido o en el domicilio de IC Intracom México, S.A. de C.V., junto con los accesorios contenidos en su empaque, acompañado de su póliza debidamente llenada y sellada por la casa vendedora (indispensable el sello y fecha de compra) donde lo adquirió, o bien, la factura o ticket de compra original donde se mencione claramente el modelo, numero de serie (cuando aplique) y fecha de adquisición. Esta garantía no es válida en los siguientes casos: Si el producto se hubiese utilizado en condiciones distintas a las normales; si el producto no ha sido operado conforme a los instructivos de uso; o si el producto ha sido alterado o tratado de ser reparado por el consumidor o terceras personas.

REGULATORY STATEMENTS

FCC Class B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of Federal Communications Commission (FCC) Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

CE / R&TTE

ENGLISH

This device complies with the requirements of the R&TTE Directive 1999/5/EC.

DEUTSCH

Dieses Gerät enspricht der Direktive R&TTE Direktive 1999/5/EC.

ESPAÑOL

Este dispositivo cumple con los requerimientos de la Directiva R&TTE 1999/5/EC.

FRANÇAIS

Cet appareil satisfait aux exigences de la directive R&TTE 1999/5/CE.

POLSKI

Urządzenie spełnia wymagania dyrektywy R&TTE 1999/5/EC.

ITALIANO

Questo dispositivo è conforme alla Direttiva 1999/5/EC R&TTE.

MANHATTAN® offers a complete line of PC Components, Peripherals, Cables and Accessories. Ask your local computer dealer for more information or visit www.manhattan-products.com.

All products mentioned are trademarks or registered trademarks of their respective owners.

MANHATTAN® bietet ein vollständiges Sortiment an PC-Komponenten, Peripherie, Kabel und Zubehör. Weitere Informationen erhalten Sie von Ihrem Händler oder auf www.manhattan-products.com.

Alle genannten Produkt- oder Firmennamen sind eingetragene Marken oder Marken der jeweiligen Firmen.

MANHATTAN® ofrece una línea completa Componentes para PC, Periféricos, Cables y Accesorios. Consulte a su distribuidor local para más información ó visitenos www.manhattan-products.com.

Todos los productos mencionados son marcas comerciales o marcas registradas de sus respectivos propietarios.

MANHATTAN® offre un assortiment complet de composants de PC, des périphériques, des câbles et des accessoires www.manhattan-products.com.

Tous les produits mentionnés sont des marques commerciales ou des marques déposées de leurs propriétaires respectifs.

MANHATTAN® to kompletna linia Komponentów PC, Peryferiów, Kabli oraz Akcesoriów. Poproś lokalnego dealera o więcej informacji lub odwiedź stronę www.manhattan-products.com.pl.

Wszystkie nazwy handlowe i towarów są nazwami i znakami towarowymi zastrzeżonymi odpowiednich firm odnośnych właścicieli.

MANHATTAN® offre una linea completa di componenti per PC, periferiche, cavi e accessori. Chiedi maggiori informazioni al tuo rivenditore di computer o visita il sito www.manhattan-products.com.

Tutti i prodotti sopracitati sono marchi di fabbrica o marchi registrati depositati dai proprietari.

MANHATTAN™

Copyright © MANHATTAN